


Skoda Fabia 2005 Fuse Box



No.	Power consumer	Amp
1	Instrument cluster, ESP	5
2	Brake lights	10
3	Power supply for the diagnostics, air-conditioning system	5
4	Interior lighting	10
5	Door warning light	5
6	Lights and Visibility	5
7	Engine electronics, power-assisted steering	5
8	Not assigned	
9	Lambda probe	10
10	S-contact ^{a)}	5
11	Electrically adjustable rear mirror ^{b)}	5
12	Ventilation system, air-conditioning system, Xenon headlight	5
13	Reversing light	10
14	Diesel engine control unit	10
15	Headlight cleaning system, window wiper	10
16	Instrument cluster	5
17	Petrol engine - control unit ^{c)}	5
18	Telephone	5
19	Automatic gearbox	10
20	Control unit for lamp failure	5
21	Heated windscreen washer nozzles	5
22	Not assigned	
23	Right main beam	10
24	Engine electronics	10
25	Control unit for ABS, TCS / control unit for ESP	5/10
26	Not assigned	
27	Not assigned	
28	Cruise control, switch for the brake and clutch pedal	5
29	Not assigned	
30	Main beam on the left and indicator light	10
31	Central locking system - door lock for the boot lid	10
32	Rear window wiper	10
33	Parking light on the right	5
34	Parking light on the left	5
35	Injector - petrol engine	10
36	Licence plate light	5
37	Rear fog light and indicator light	5

38	Heating of the external mirror	5
39	Rear window heater	20
40	Horn	20
41	Front window wiper	20
42	Cigarette lighter, power socket	15
43	Central control unit, selector lever lock for automatic gearbox	20
44	Turn signals	15
45	Radio, navigation system	20
46	Electrical power window (at the front on the right)	25
47	Not assigned	
48	Diesel engine - control unit, injector	30
49	Central locking system	15
50	Low beam on the right	15
51	Power socket in the luggage compartment	15
52	Ignition	15
53	Electrical power window (at the rear on the right)	25
54	Low beam on the left	15
55	Not assigned	
56	Control unit - petrol engine	20
57	Towing device	25
58	Electrical power window (at the front on the left)	25
59	Not assigned	
60	Horn for the anti-theft alarm system	15
61	Fuel pump - petrol engine	15
62	Electric sliding/tilting roof	25
63	Seat heaters	15
64	Headlight cleaning system	20
65	Fog lights	15
66	Electrical power window (at the rear on the left)	25
67	Not assigned	
68	Fresh air blower	25

- a) For power consumers, e.g. the radio, which can be operated with the ignition switched off as long as the ignition key is not withdrawn
- b) For vehicles with an electrical power window system
- c) It is 15 amps for a vehicle with a 1.2 litre engine