

Groups 120 - 129: Communcations between Control Modules

120	ASR/FDR			
	Engine RPM	Specified moment ASR/FDR	Engine moment	Status
	[1/min]	[Nm]	[Nm]	Text (ASR active/ASR not active)
121				
122	Transmission			
	Engine RPM	Specified moment Transmission	Engine moment	Status
	[1/min]	[Nm]	[Nm]	Text (Engine intervention /no intervention)
123	Reserved for CAN Bus signals			
124	Reserved for CAN Bus signals			
125	CAN Bus signals			
	see CAN-Product Description Manual			
	Transmission ^[1]	ABS ³²	Instrument cluster ³²	A/C ³²
126	CAN Bus signals			
	ADR 32	LWS 32	Airbag ³²	Electrical wiring ³²
127	CAN Bus signals			
	All wheel ³²	Level	Steering wheel	
128	CAN Bus signals			
129	CAN Bus signals			

^[1] This corresponds with the desired sequence. Should there be no participant available a gap will remain at this place.